

Assembly Instructions for

EP-5920 EP-5940

Horizontal Kraft Paper Dispensers

1. Assemble T-Stand



Insert threaded rods (E5920-08) through the holes in the left T-stand (E5920-01-L) and the right T-Stand (E5920-01-R).

Secure each end with a cap nut (E5920-11).

2. Adjust Hex Nuts



Tighten and adjust the **hex nuts (E5920-10)** so that both of the T-stands are parallel and square to each other.

3. Attach Paper Strips



Attach the paper strip (E5920-07) to the bolts (E5920-03).

Secure the strip to the bolts using cap nuts (E5920-04).

4. Finished Product



Mount the **center support (E5920-06)** onto both. T-stands.

The EP-5920/EP-5940 assembly is complete and the unit is ready for use.

