



Instructions for EP-760-1L and EP-760-1S



Step One: Untighten the wing so that the stretch film can slide on.

Step Two: Slide the stretch film on to the hand dispenser.



Step Three: Tighten the wing so that the rubber expands, to hold the stretch film in place.



Step Four: Untighten the wing to replace the roll.

