



EP-3100 Assembly Instructions



1. Lay cart on its back with the threaded rod pointing up.



2. Remove Spin Nut and front disk.



3. Lay Strapping on back disk with the center surrounding the threaded rod, then place front disk on and tighten Spin Nut.



4. Thread Strapping through feeder.



5. Bring cart into upright position and you are now ready to effectively use the EP-3100!

Safety Warning

- Wear safety glasses. Failure to wear safety glasses with side shield could result in serious eye injury or blindness. All operators and bystanders must always wear safety glasses with side shields that conform to ANSI Standard Z87.1 or European Norm 166
- Wear Gloves when handling strapping and sharp parts to reduce the risk of cuts to your hands.
- Follow any additional personal protective clothing and equipment guidelines designated by your facility.
- Always use new strapping. Never use used strapping.